

UL for Linux Library

USB

Measurement Computing

OEM variants are also supported.

- | | | | |
|--------------------------------|------------------|----------------|-----------------|
| • AI-EXP32 | • USB-1608HS | • USB-2627 | • USB-DIO24H/37 |
| • SC-1608-USB | • USB-1608HS-2AO | • USB-2633 | • USB-DIO32HS |
| • SC-1608X-2AO-USB | • USB-1808 | • USB-2637 | • USB-DIO96H |
| • SC-1608X-USB | • USB-1808X | • USB-3101 | • USB-DIO96H/50 |
| • USB-1024HLS | • USB-2001-TC | • USB-3102 | • USB-ERB08 |
| • USB-1024LS | • USB-201 | • USB-3103 | • USB-ERB24 |
| • USB-1208FS-Plus | • USB-202 | • USB-3104 | • USB-PDISO8 |
| • USB-1208HS-2AO ¹ | • USB-2020 | • USB-3105 | • USB-PDISO8/40 |
| • USB-1208HS-4AO ¹ | • USB-204 | • USB-3106 | • USB-QUAD08 |
| • USB-1208HS ¹ | • USB-205 | • USB-3110 | • USB-SSR08 |
| • USB-1408FS-Plus | • USB-2408 | • USB-3112 | • USB-SSR24 |
| • USB-1608FS-Plus ¹ | • USB-2408-2AO | • USB-3114 | • USB-TC |
| • USB-1608G | • USB-2416 | • USB-CTR04 | • USB-TC-AI |
| • USB-1608GX | • USB-2416-4AO | • USB-CTR08 | • USB-TEMP |
| • USB-1608GX-2AO | • USB-2623 | • USB-DIO24/37 | • USB-TEMP-AI |

¹ [Firmware version 1.07](#) or later required.

Data Translation

- DT9837A
- DT9837B
- DT9837C

Third-Party Drivers

USB

OEM variants are also supported.

- | | | | |
|--------------------|-------------------|------------------|----------------|
| • miniLAB-1008 | • USB-1208HS-2AO | • USB-1608HS | • USB-205 |
| • SC-1608-USB | • USB-1208HS-4AO | • USB-1608HS-2AO | • USB-2408 |
| • SC-1608X-2AO-USB | • USB-1208LS | • USB-1616FS | • USB-2408-2AO |
| • SC-1608X-USB | • USB-1408FS | • USB-1808 | • USB-2416 |
| • TC-32 | • USB-1408FS-Plus | • USB-1808X | • USB-2416-4AO |
| • USB-1024HLS | • USB-1608FS | • USB-2001-TC | • USB-2623 |
| • USB-1024LS | • USB-1608FS-Plus | • USB-201 | • USB-2627 |
| • USB-1208FS | • USB-1608G | • USB-202 | • USB-2633 |
| • USB-1208FS-Plus | • USB-1608GX | • USB-2020 | • USB-2637 |
| • USB-1208HS | • USB-1608GX-2AO | • USB-204 | • USB-3101 |

Third-Party Drivers (continued)

USB

- USB-3102
- USB-3103
- USB-3104
- USB-3105
- USB-3106
- USB-3110
- USB-3112
- USB-3114
- USB-7202
- USB-7204
- USB-CTR04
- USB-CTR08
- USB-DIO24/37
- USB-DIO24H/37
- USB-DIO32HS
- USB-DIO96H
- USB-DIO96H/50
- USB-ERB08
- USB-ERB24
- USB-PDISO8
- USB-PDISO8/40
- USB-SSR08
- USB-SSR24
- USB-TC
- USB-TC-AI
- USB-TEMP
- USB-TEMP-AI

Ethernet

OEM variants are also supported.

- E-1608
- E-DIO24
- E-TC
- TC-32

PCI, PCIM, and PCIe

- PCI-DAS08
- PCI-DAS1000
- PCI-DAS1001
- PCI-DAS1002
- PCI-DAS1602/16
- PCI-DAS4020/12
- PCI-DDA02/12
- PCI-DDA04/12
- PCI-DDA04/16
- PCI-DDA08/12
- PCI-DDA08/16
- PCI-DIO24
- PCI-DIO24/LP
- PCI-DIO24/S
- PCI-DIO24H
- PCI-DIO48H
- PCI-DIO96
- PCI-DIO96H
- PCI-QUAD04
- PCIe-DAS1602/16
- PCIe-DIO24
- PCIe-DIO96H
- PCIM-DAS1602/16
- PCIM-DAS16JR/16
- PCIe-DAS1602/16

MCC DAQ HATs for Raspberry Pi

The following table lists the MCC hardware supported by the MCC DAQ HAT Library. OEM variants are also supported.

- MCC 118
- MCC 134
- MCC 152